




ACTIVE HEAT FLEX PARTS LIST

The following is a list of the most common replacement parts, their descriptions, and ordering SKU(s) for the active heat flex heat management system.

HEAT FLEX COVER & SIDES



Part Name	Description	SKU
COV-30	Replacement Heat Flex Cover for 30" Fireplace	COV30
COV-42	Replacement Heat Flex Cover for Traditional 42" Fireplace	COV42
COV-45	Replacement Heat Flex Cover for 45" Fireplace	COV45
COV-46	Replacement Heat Flex Cover for Traditional 46" Fireplace	COV46
COV-50	Replacement Heat Flex Cover for 50" Fireplace	COV50
COV-60	Replacement Heat Flex Cover for 60" Fireplace	COV60
COV-70	Replacement Heat Flex Cover for 70" Fireplace	COV70
COV-80	Replacement Heat Flex Cover for 80" Fireplace	COV80
COV-100	Replacement Heat Flex Cover for 100" Fireplace	COV100
COV-PASS	Replacement Heat Flex Cover for Passage Fireplace	COVPASS
HFS-R	Replacement Heat Flex Side for R (16") Fireplace	HFSR
HFS-H	Replacement Heat Flex Side for H (24") Fireplace	HFSH
HFS-EH	Replacement Heat Flex Side for EH (30") Fireplace	HFSEH

ACTIVE HEAT FLEX ADAPTERS AND FLEX PIPE

Part Name	Description	SKU
4SK-ADP	4" Adapters	4SKADP
4DFA-25	4" DuraFlex Pipe	4DFA25



Model Size	Part Name	Description	SKU
30	ACT-IN-1	Active Heat Flex Inline Fan	ACTIN1
45			
50			
60			
70			
80	ACT-IN-2	Active Heat Flex Inline Fans	ACTIN2
100			
30	ACT-EOL-1	Active Heat Flex End of Line Fan	ACTEOL1
45			
50			
60			
70			
80	ACT-EOL-2	Active Heat Flex End of Line Fans	ACTEOL2
100			

Part Name	Description	SKU
ZERO-BRD	Zero Clearance Control Board	ZEROBRD
PV-CB	Power Vent Control Board	PVCB
6-CVR-PLATE	6" Cover Plate	6CVRPLATE
64-AD-PLATE	6" to 4" Adapter Plate	64ADPLATE