



FLARE FIREPLACES | ADDING A POWER VENT TO AN EXISTING SYSTEM

SCREENED UNITS

PART NAME & SKU

1. High Voltage Power Vent (In-Line and End-of-Line Horizontal or Vertical) | [100IPV](#), [100HPV](#), [100VPV](#)
2. 3x5 Starter Collar (Vent Adapter) | [35CVSADP](#)
3. Power Vent Pigtail(s) | [PVCBL](#)
4. SIT V5 Control Board | [1SITCBV5](#)
5. SIT V5 Double Glass Relay Kit | [1SITDGRL5](#)
6. SIT 110 Cable with Molex | [1SITX1-M](#)

DOUBLE GLASS UNITS

PART NAME & SKU

1. High Voltage Power Vent (In-Line and End-of-Line Horizontal or Vertical) | [100IPV](#), [100HPV](#), [100VPV](#)
2. 3x5 Starter Collar (Vent Adapter) | [35CVSADP](#)
3. Power Vent Pigtail(s) | [PVCBL](#)