

# FLARE

## FIREPLACES

---

### Flare Fireplaces FAQ | Honeywell and SIT Valve Comparison

All **Indoor** Flare Fireplaces ship with the SIT ProFlame II Gas Valve system. All **Outdoor** Flare Fireplaces ship with the Honeywell Gas Valve System.

<b><u>FEATURE</u></b>	<b><u>HONEYWELL</u></b>	<b><u>SIT</u></b>
Wall Switch	YES	YES
Optional Remote	NO	YES
Auto Restart	YES	NO
Power	110V - Must Be Wired To A Switch	110V Input
Wall Switch Included	NO	YES
Flame Height Control	NO	YES