



Flare See Through Wood Frame^{Rev 4} Extra High Glass

Fireplace Dimensions









Flat Vs. L Shape Installation For FLARE Front Fireplace

Heat Release and Air Intakes

The following sizes MUST be maintained for the upper heat release:

For fireplaces sized **80" & 100"**– open vent area must be at least **200 square inches.**

For fireplaces sized **60" & 70"** – open vent area must be at least **140 square inches**.

For fireplace sized **50**" and below – open vent area must be at least **100 square inches.**

The following sizes MUST be maintained for the lower air intake: For fireplaces sized 80" & 100" – open vent area must be at least 100 square inches.

For fireplaces sized **60" & 70"** - open vent area must be at least **70** square inches.

For fireplaces sized **50**" and below - open vent area must be at least **50 square inches.**


For See Through and Room Definer fireplaces, the air intake requirements are **double**.

NOTE: Openings above for Heat Release and Air Intake are measured for open air space. BE SURE TO CALCULATE FOR RESTRICTIONS IN GRATING.

NOTE: On all **See Through** and **Room Definer** units the air intake must be doubled

Air Intakes required for Double Glass or Optional Blower kits ONLY.


Top Shadow Line





Wood Framing Dimensions

Rev 04



NOTE: Dimension 'Y' uses legs at default lowest height 4" below the unit with glass beginning 10" above the floor. Increase leg height and Y dimension for higher viewing window.

	v		Y -	Ζ	
		X		Flat Installation	Recess Installation (4" Max)
45	Inch	51 9/16	64 11/16	18 1/16	26 1/16
	mm	1294	1643	459	662
50	Inch	58 5/16	64 11/16	18 1/16	26 1/16
	mm	1481	1643	459	662
60	Inch	68 2/16	64 11/16	18 1/16	26 1/16
	mm	1730	1643	459	662
70	Inch	77 15/16	64 11/16	18 1/16	26 1/16
	mm	1980	1643	459	662
80	Inch	90 9/16	64 11/16	18 1/16	26 1/16
	mm	2300	1643	459	662
100	Inch	107 8/16	64 11/16	18 1/16	26 1/16
	mm	2731	1643	459	662